KRISSKYDD

Överfallslarm med blixt

Bruksanvisning · User manual

Svenska

Tack för att du valt Krisskydd. Läs hela bruksanvisningen innan du använder överfallslarmet och spara den för framtida bruk.

Produktbeskrivning

- Personligt larm för nödsituationer – bär det på väskan, nyckelknippan eller i fickan.
- Kraftig siren på cirka 130 dB som startar direkt när du drar ut sprinten med kedjan.
- Två sirener med olika frekvens ljuder samtidigt, vilket gör ljudet svårt att ignorera.
- Inbyggd LED-lampa så att du ser och syns i mörker.
- Drivs av 2 × AAA/LR03-batterier.

Produktens delar

1. Larmenhet
2. Siren
3. Knapp för LED-lampa (på sidan)
4. LED-lampa
5. Kedja med sprint och nyckelring



Säkerhet

- Sirenen är mycket stark och kan på nära håll ge bestående hörselskador. Håll aldrig larmet intill örat.
- Utsätt inte barn eller husdjur för sirenljudet. Larmet är ingen leksak.
- Rikta aldrig LED-lampan direkt mot ögonen.
- Blanda inte gamla och nya batterier, eller batterier av olika typer.
- Ta ur batterierna om larmet inte ska användas på länge – gamla batterier kan läcka och skada larmet.
- Överfallslarmet är ett hjälpmedel och ersätter inte nödnumret. Ring 112 vid akut fara.

Användning

Utlösa larmet

1. Dra ut sprinten ur larmenheten med hjälp av kedjan eller nyckelringen. Sirenen startar direkt.
2. Sirenen ljuder tills du trycker tillbaka sprinten i larmenheten.

Tända LED-lampan

Håll in knappen på sidan av larmet. Lampan lyser så länge du håller in knappen.

Bära larmet

Fäst larmet där du snabbt når det, till exempel på väskans axelrem eller på nyckelknippan.

Testa larmet

Testa larmet ibland, till exempel en gång i månaden, så att du vet att det fungerar när det behövs. Håll larmet på armslängds avstånd, dra ut sprinten en kort stund och sätt sedan tillbaka den.

Byta batterier

Byt batterierna när sirenen låter svagare än vanligt. Är du osäker kan du mäta batterierna med en batteritestare.

1. Håll larmet stadigt i ena handen.
2. Skruva ur skruven på batteriluckan och ta bort luckan.
3. Ta ur de gamla batterierna.
4. Sätt i två nya AAA/LR03-batterier. Följ plus- och minusmarkeringarna i batterifacket.
5. Sätt tillbaka luckan och skruva fast den ordentligt.
6. Testa att larmet fungerar.

Skötsel och underhåll

Torka av larmet med en mjuk, lätt fuktad trasa. Använd vid behov ett milt rengöringsmedel. Använd aldrig lösningsmedel eller starka, slipande medel – de kan skada produkten.

Avfallshantering

Symbolen med den överkorsade soptunnan betyder att produkten inte får slängas med hushållsavfallet. Det gäller i hela EU. Lämna produkten och förbrukade batterier till en återvinningscentral eller insamlingsplats för elektronik, så tas materialet om hand på ett ansvarsfullt sätt.



Specifikationer

Egenskap	Värde
Ljudnivå	ca 130 dB
Batterier	2 × AAA/LR03
Mått	85 × 30 × 19 mm
Belysning	LED-lampa

Kundtjänst

Har du frågor om produkten? Kontakta Krisskydds kundtjänst via www.krisskydd.se.

Krisskydd Sverige AB · Bruksgatan 3, 711 72 Vedevåg · www.krisskydd.se

Vi reserverar oss för eventuella text- och bildfel samt ändringar av tekniska data.

English

Personal Attack Alarm with Light

Thank you for choosing Krisskydd. Please read this entire manual before using the alarm and keep it for future reference.

Product description

- Personal alarm for emergency situations – carry it on your bag, your keys or in your pocket.

- Powerful siren of approx. 130 dB that sounds instantly when you pull out the pin with the chain.
- Two sirens at different frequencies sound at the same time, making the alarm hard to ignore.
- Built-in LED light so you can see and be seen in the dark.
- Powered by 2 × AAA/LR03 batteries.

Parts

1. Alarm unit
2. Siren
3. LED light button (on the side)
4. LED light
5. Chain with pin and keyring



Safety

- The siren is very loud and can cause permanent hearing damage at close range. Never hold the alarm next to your ear.

- Do not expose children or pets to the siren. The alarm is not a toy.
- Never point the LED light directly at anyone's eyes.
- Do not mix old and new batteries, or batteries of different types.
- Remove the batteries if the alarm will not be used for a long time – old batteries can leak and damage the alarm.
- The alarm is an aid and does not replace emergency services. In an emergency, call 112 (EU) or your local emergency number.

Use

Activating the alarm

1. Pull the pin out of the alarm unit using the chain or keyring. The siren starts immediately.
2. The siren keeps sounding until you push the pin back into the alarm unit.

Using the LED light

Press and hold the button on the side of the alarm. The light stays on for as long as you hold the button.

Carrying the alarm

Attach the alarm where you can reach it quickly, for example on your bag strap or your keyring.

Testing the alarm

Test the alarm from time to time, for example once a month, so you know it works when you need it. Hold the alarm at arm's length, pull out the pin briefly and then push it back in.

Changing the batteries

Change the batteries when the siren sounds weaker than usual. If you are unsure, check the batteries with a battery tester.

1. Hold the alarm firmly in one hand.
2. Unscrew the battery cover screw and remove the cover.
3. Take out the old batteries.
4. Insert two new AAA/LR03 batteries, following the + and – markings in the battery compartment.
5. Refit the cover and screw it firmly in place.
6. Test that the alarm works.

Care and maintenance

Wipe the alarm with a soft, slightly damp cloth. Use a mild cleaning agent if needed. Never use solvents or strong, abrasive cleaners – they can damage the product.

Responsible disposal

The crossed-out wheelie bin symbol means this product must not be thrown away with household waste. This applies throughout the EU. Take the product and used batteries to a recycling centre or an electronics collection point, so the materials can be handled responsibly.



Specifications

Feature	Value
Sound level	approx. 130 dB
Batteries	2 × AAA/LR03
Dimensions	85 × 30 × 19 mm
Light	LED light

Customer service

Questions about the product? Contact Krisskydd customer service via www.krisskydd.se.

Krisskydd Sverige AB · Bruksgatan 3, SE-711 72 Vedevåg, Sweden · www.krisskydd.se

We reserve the right to errors in text or images and to changes in technical data.